HIGH NOON
STAGE PRODUCTIONS

19 - 23 Belvedere Court,
Chambers Flat. QLD 4133
www.highnoon.com.au
ABN: 56113820515

(07) 38 021 500
0 4 1 8 8 8 0 5 7 6
dyke@highnoon.com.au
ACN: 083021014

HighNoon 10.1w LED with IP DMX Connectors

No.	Display	Function description
1	D.001	4 channels address, press button up/down to change the data（001—512）
2	A.001	8 channels address， press button up/down to change the data（001—512）
3	r.000	Red，（000—255） Press up/down to change brightness
4	g.000	Green，(000—255)Press up/down to change brightness
5	b.000	Blue，（000—255） Press up/down to change brightness
6	U.000	White，(000—255)Press up/down to change brightness
7	FH.00	Strobe，（1—99） press button up/down to change speed
8	CL.01	Manually change color（1—9）press button up/down to change color
9	CC.71	Color jumping（1—99）press button up/down to change speed
10	dE.72	color change gradually （1—99） button up/down to change speed
11	CP.73	Pulse change（1—99）button up/down to change , speed up/down
12	SOU.9	9： color change via sound control;1 — 8 strobe via sound control

3. DMX512 4 channels introduction

Channels	Function	Function introduction
1	R dimming	R dimming from dark to bright
2	G dimming	G dimming from dark to bright
3	B dimming	B dimming from dark to bright
4	W dimming	W dimming from dark to bright

4. DMX512 8 channels introduction

Channels	Function	Function introduction
CH 1	General dimming	R、G、B、W colors general dimming linear dimming, from dark to bright
CH 2	R dimming	R dimming from dark to bright
CH 3	G dimming	G dimming from dark to bright
CH 4	B dimming	B dimming from dark to bright
CH 5	W dimming	dimming from dark to bright
CH 6	Strobe	Strobe speed, from slow to fast