

# DJ POWER V-1 COLD SPARK MACHINE



## 2CH MODE

| CHANNEL | FUNCTION      | VALUE/RANGE | PERCENT/SETTING                  |
|---------|---------------|-------------|----------------------------------|
| 1       | SPARK HEIGHT  | 000 ⇄ 009   | Spark OFF                        |
|         |               | 010 ⇄ 035   | Spark height level 1             |
|         |               | 036 ⇄ 060   | Spark height level 2             |
|         |               | 061 ⇄ 085   | Spark height level 3             |
|         |               | 086 ⇄ 110   | Spark height level 4             |
|         |               | 111 ⇄ 135   | Spark height level 5             |
|         |               | 136 ⇄ 160   | Spark height level 6             |
|         |               | 161 ⇄ 185   | Spark height level 7             |
|         |               | 186 ⇄ 210   | Spark height level 8             |
|         |               | 211 ⇄ 235   | Spark height level 9             |
|         |               | 236 ⇄ 255   | Spark height level 10            |
| 2       | SPARK CONTROL | 000 ⇄ 009   | Device enabled                   |
|         |               | 010 ⇄ 060   | Consumable cleaning up           |
|         |               | 061 ⇄ 120   | Emergency stop / Device disabled |
|         |               | 121 ⇄ 182   | Auto Heat-up OFF (Ch1 Disabled)  |
|         |               | 183 ⇄ 255   | Auto Heat-up ON (Ch1 Disabled)   |