

HighNoon Dual COB Led Blinder

DMX functions and their values (14 DMX channels):

Channel	Value	Function
1		<u>PAN Movement 8bit :</u>
	0-255	Pan Movement
2		<u>Pan Fine 16bit</u>
	0-255	Fine control of Pan movement
3		<u>TILT Movement 8bit :</u>
	0-255	Tilt Movement
4		<u>Tilt Fine 16bit</u>
	0-255	Fine control of Tilt movement
5		<u>Red LED :</u>
	0-255	Red (0-Black , 255-100% Red)
6		<u>Green LED :</u>
	0-255	Green (0-Black , 255-100% Green)
7		<u>Blue LED :</u>
	0-255	Blue (0-Black , 255-100% Blue)
8		<u>White LED :</u>
	0-255	White (0-Black , 255-100% White)
9		<u>Shutter, strobe:</u>
	0-31	Led trun off
	32-63	Led turn on
	64-95	Strobe effect slow to fast